

35000-400 CENTRAL VAC PAY SYSTEM Models-

V CANOPY

Page 2 **Product Information**

Page 3,4 **Specifications**

Page 5 **Product Dimensions**

Page 6-8 Control Box Installation

Page 9,10 Solenoid and Valve Installation

Page 11 Control/ Faceplate Installation

Page 12 Maintenance, Operation

Page 13-19 **Parts**



PRODUCT INFORMATION

Please take a moment to fill out the information below in order to aid us with any future sales or service inquiries. Model number and serial number information can be found on the serial tag located inside the control box and/or on the lower exterior of the can. Key number can be found on the tag that comes attached to the keys. There may be more than one key number depending on unit.

Please keep this information with your records.

J.E. Adams Industries 1025 63rd Ave. S.W. Cedar Rapids, IA 52404 1-800-553-8861

www.jeadams.com

Specifications

Pay system will work with existing V canopy formation, with following additions:


- -Valve kit, single 3" valve (comes with control solenoid)
- -Control/pay box (tall box only, uses long face plates, left or right post mounting)
- -Control faceplate assemblies (standard combinations available)
- -Customer supplied air source (90 PSI maximum pressure)

NOTE: This manual is for central vac pay system only. If installing new system you must use 35000-11 manual which has details of installation of stanchions, arches and canopies along with accessories.

Pay system works with standard accessories:

- Locking trash receptacle
- Stainless steel mat rack
- Mat clamp
- Claw tool holster
- Crevice tool holster
- Optional V shade canopy
- Optional LED Lighting

Theory of Operation: Each stanchion has a Control / Pay box and a single valve that controls both arches attached to that Stanchion. Each stanchion is autonomous.



Specifications Cont.

Unit specifications: Per Control Box Assembly (LED7 Display version)


Voltage: 120vac, 60hz


Amperage: Weight:


15 amp 35000-400-4A (Control Box Assembly) 48 lbs 35000-400-20A (Face Plate Assembly) 14 lbs 9202-60A or 9202-64A (Pre-Collector) 27 lbs.





NOTE: This manual covers only the Pay Central Vac system and is not intended to replace the standard install manual. Standard installation instructions must be followed in manual 35000-11 DUAL ARCH STANCHION


















Maintenance:


- Pre-collectors dirt bins must be emptied on a daily basis or as needed. Large particulate such as pens, coins, jewelry, bolts, etc. will be collected here.
- Gaskets on pre-collectors must be checked for wear once a week or as needed.
- Nuts and bolts on structure should be checked once a month or as needed.
- Fabric canopies should be taken down before severe weather situations.
- Powder coated parts will eventually wear over time. JE Adams offers touch up paint to keep your parts looking great.
- Stainless steel parts should be wiped/ cleaned as needed.
- Verify daily that system air pressure is not exceeding the operational maximum of 90 PSI


Operations:


- Valves in their off state have pressure on an internal bladder that keeps them from flowing vacuum pressure. When customer purchases time at a vacuum drop the solenoid allows the air pressure to bleed off the valve/s associated with that drop location thus allowing vacuum pressure at the hoses. It is best to operate valves at lowest pressure possible while still closing off majority of vacuum pressure (50 to 60 PSI) This will prolong life of valve and reduce stress on internal rubber bladder.
- *When central vacuum system is deactivated (producer is powered down) it is vitally important that the supply pressure to valves is also disconnected at source and allowed to bleed off so valves remain in relaxed state during shut off. This will prevent bladders in valves from taking a set and not opening completely when in use.
- System can become a free vend system again by simply removing supply air pressure at source and allow all valves to bleed off their pressure.



| BILL OF MATERIALS | | | | | | | |
|-------------------|---------------|--------------------------------|-----|--|--|--|--|
| ITEM | PART NUMBER | DESCRIPTION | QTY | | | | |
| 1 | 35000-400-10A | AIR VALVE ASY, 2 VALVE, CV PAY | 1 | | | | |
| 2 | 35000-400-31 | COUPLING 3" ID X 3.5" ID | 2 | | | | |
| 3 | 35000-400-34 | HOSE ASY, CV PAY AIR, 18" | 1 | | | | |
| 4 | 35000-400-3V | VALVE, PINCH, 3" DIA. ENDS | 1 | | | | |









| UNSPECIFIED | MATERIAL | | CEDAR RAPIDS | , IOWA |
|---------------------------|----------------|-------|---|--------|
| 1 PL ± .030 | DRAWN BY IT | IWS | CONTRACTOR OF THE PROPERTY OF | |
| 2 PL ±.020 | 2/28/2020 | | CINE TRIES. | TO |
| 3 PL ± .003 ANGLE ± 1* | 0.16:1 | 1 / 1 | 35000-400-3VA | REU. |


- 8566 RELEASED 4/20/20 MWS 2

REV NO. DESCRIPTION DATE BY

THIS DOCUMENT SHALL NOT BE REPRODUCED NOR SHALL THE INFORMATION THEREIN BE USED BY OR DISCLOSED TO OTHERS EXCEPT AS AUTHORIZED BY J.E. ADAMS INDUSTRIES







THIS DOCUMENT SHALL NOT BE REPRODUCED NOR SHALL THE INFORMATION THEREIN BE USED BY OR DISCLOSED TO OTHERS EXCEPT AS AUTHORIZED BY J.E. ADAMS INDUSTRIES

35000-400-20A

1/1

ANGLE ±1°

CEDAR RAPIDS, IOW

QTY

