

Models: 6025, 6025-DIG, 6026 and 6026-DIG Hose Reel Base

Product Information Page 2

Important Safety Information Page 3

Specifications Page 3

Dimensions Page 4

Mounting Page 5-7

Assembly Page 8

Service Page 9,10

Drawings Page 11-16





PRODUCT INFORMATION

Please take a moment to fill out the information below in order to aid us with any future sales or service inquiries. Model number and serial number information can be found on the serial tag located inside the control box and/or on the lower exterior of the can. Key number can be found on the tag that comes attached to the keys. There may be more than one key number depending on the unit.

Please keep this information with your records.

MODEL#:	
SERIAL#:	
KEY NUMBER(S):	
DATE PURCHASED:	
DISTRIBUTOR:	

J.E. Adams Industries 1025 63rd Ave. S.W. Cedar Rapids, IA 52404 1-800-553-8861

www.jeadams.com

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING (THIS APPLIANCE)

WARNING – To reduce the risk of fire, electric shock, or injury:

- Do not use on wet surfaces.
- Use only as described in manual. Use only manufactures recommended attachments.
- Do not állow to be used as a toy. Close attention is necessary when used by or near children.
- Do not put any object into openings. Do not use with any opening blocked; do not reach inside base when operating.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Maintain rollers at hose entrance into reel base. Failure to do so will prematurely shorten hose life.
- Be careful of sharp edges on sheet metal parts.


SAVE THESE INSTRUCTIONS

Installation Instructions:

- Determine location to mount unit ("DANGER" "THIS EQUIPMENT INCORPORATES PARTS SUCH AS SWITCHES, MOTORS, OR THE LIKE THAT TEND TO PRODUCE ARCS OR SPARKS THAT CAN CAUSE AN EXPLOSION. WHEN LOCATED IN GASOLINE-DISPENSING AND SERVICE STATIONS INSTALL AND USE AT LEAST 20 FEET (6 M) HORIZONTALLY FROM THE EXTERIOR ENCLOSURE OF ANY DISPENSING PUMP AND AT LEAST 18 INCHES (450 MM) ABOVE A DRIVEWAY OR GROUND LEVEL."
- Run service to the location
- **Grounding Instructions**: This appliance must be connected to a grounded metal, permanent wiring system; or an equipment-grounding conductor must be run with the circuit conductors and connected to the equipment-grounding terminal or lead on the appliance.
- Circuit must be protected by GFCI device.
- All local and national electric codes must be followed for installation and use.
- Licensed electricians are recommended for installation.


Specifications:

- Weight: 95 lbs (6025), 75 lbs (6026).
- · Heavy item, use caution when positioning unit.



Mounting:


• Find suitable location that will allow reasonable service access to machine mounted on top of base, consider door swing of this mounted machine in the assessment. Drill and place 5 concrete anchors of your choice (at least 3/8" diameter hardware) at least 4" into concrete. Always Mount base to concrete first then mount machine to top of base.




Mounting Cont.:

Consideration for routing electrical and water supply. These can be plumbed under ground and enter under the reel base, routed up right side to machine mounted on top of reel base.


REEL BASE WITH MACHINE ON TOP BOTTOM VIEW:



Electrical access point into machine mounted on top of reel base




Bottom view of base with machine installed.





Reel Base must be securely fastened to ground before placing machine unit on top.



Hose service when unit is installed and machine in place on top:

Step 1: When machine is installed over base, first loosen (4) 5/16 bolts holding machine to base, remove front two 1/4-20 screws if present.


Step 2: Removed hose end on hose to be replaced


Step 3: Pull a couple feet of hose out and hold tension while removing the rubber hose stop. Do not let go of hose, still under tension, may damage reel.

Step 4: Remove (2) cover screws each side, and pull cover off front of unit.


Step 5: Hold reel as hose is released and slowly allow reel to spin to relax spring. Note the number of turns needed to relax reel tension.

Step 6: Pre-spin reel based on turns counted when removing hose (spin top fo spool towards front of unit). Hold reel or clamp edge to hold from spinning. Route new hose under Ubolt on reel and into opening in reel hub, connect to swivel (90 deg. Fitting). Verify tension is appropriate to reel hose, then reverse process above for reassembly.







Reel Return Spring Service:




Spring Housing Assembly, 6025-8RC



Step 1: After reel is removed from base slowly allow spring tension to relieve if not already relaxed. Disconnect hose end from 90 deg. fitting. Remove center swivel fitting and snap ring.






Step 2: Remove (4) phillips head screws on mounting bracket



Step 4: Make sure spring and hub interface correctly. Pre-spin bracket side counter clockwise to pretention hose.



Step 3: Pull bracket and spring housing out, spring housing assembly should be free to disengage the reel and reel mounting bracket. Replace with new Spring housing.

