

Canister Maintenance

- Clean the outside of your vacuum
 - Never use:
 - Harsh abrasives
 - Steel wool
 - Any kind of brush
 - Use soapy water and a clean cloth
 - Stainless steel cleaner

